



Wi-Fi Channel Selection & Splitting SSIDs



Login Page

- 1 Enter <http://192.168.1.1/> into your browser whilst you are connected to your Vodafone Home Broadband.
- 2 The password to login is **vodafone**

1



Vodafone Connect

Welcome

Enter your Vodafone Connect router password to manage your settings.

2

Log In

Forgotten password


Firmware version: 5.4.8.1.291.1.30.1.29
WAN IP Address: 87.75.108.226



Splitting SSIDs and changing Wi-Fi settings.

If you don't want a device to automatically select which band to connect to, you can split the 2.4Ghz and 5Ghz bands into two separate SSIDs.

The option to do this exists in both basic and advanced mode under the Wi-Fi tab > General Wi-Fi settings - as shown below.



Splitting SSIDs and changing Wi-Fi settings cont.

By default you will see the following in the general settings area;

Overview

Internet

Wi-Fi

Sharing

Settings

Status & Support

General

Schedule

WPS

General Wi-Fi settings

Your Vodafone Connect router conforms to recognised Wi-Fi standards, and enables your devices to be easily connected wirelessly.

Wi-Fi network

☒

Enable Wi-Fi On/Off button on Vodafone Connect router

☒

Split SSID

☐

Setup

Main Wi-Fi

Wi-Fi 2

Wi-Fi name (SSID)

VodafoneConnect92213879

Broadcast SSID

☒

Frequency

2.4 / 5 GHz

Protection mode

WPA + WPA2

Wi-Fi password

.....

Display characters ☐

Change password

The “Wi-Fi” 2 option is the guest network which by default is off, you can enable and configure this here as well.



Splitting SSIDs and changing Wi-Fi settings cont.

Once the option is enabled you'll see two Wi-Fi networks underneath;

Split SSID



Setup

Main Wi-Fi (2.4 GHz)

Wi-Fi name (SSID)

VodafoneConnect92213879

Broadcast SSID



Protection mode

WPA + WPA2



Wi-Fi password

••••••••

Display characters

☐

Change password

Main Wi-Fi (5 GHz)

Wi-Fi name (SSID)

VodafoneConnect92213879

Broadcast SSID



Protection mode

WPA + WPA2



Wi-Fi password

••••••••

Display characters

☐

Change password

You will now be able to configure these as two separate Wi-Fi networks.



Splitting SSIDs and changing Wi-Fi settings cont.

To change the Wi-Fi mode / bandwidth and channel for each frequency you will need to enter “Expert mode” and navigate to “settings” within the Wi-Fi tab.

Overview	Internet	Wi-Fi	Sharing	Settings	Status & Support
<div>Basic Mode</div>			<div>Expert Mode</div>		
<div>General</div>			<div>General</div>		
<div>Schedule</div>			<div>Schedule</div>		
<div>WPS</div>			<div>WPS</div>		
			<div>MAC Filter</div>		
			<div>Settings</div>		



Splitting SSIDs and changing Wi-Fi settings cont.

Here you can select the dropdown menu to change the bandwidth and channels of both 2.4Ghz and 5Ghz bands.

Settings



Below you can change parameters for the two WiFi frequencies 2.4 GHz and 5 GHz.

2.4 GHz

WiFi Mode	Mixed 802.11b/g/n	▼
Bandwidth	20MHz	▼
Channel	Auto	▼

5 GHz

WiFi Mode	802.11ac (default)	▼
Bandwidth	20/40/80MHz	▼
Channel	Auto	▼

